
→ ASST Lattice Towers


Modular Towers & Columns



ASST Foundation ← & Installation Methods

Modular Towers & Columns

ASST



Allow 72 hours after pouring concrete before installing pole or tower

Please note that foundation sizes shown in the table above are in accordance with recommended headload andwindload capacities shown in technical specification tables For increased headloads – foundations may need to increase in size – please contact us for revised foundation sizes for specific installations.

ACTUAL WIND VELOCITY FOR THESE WINDSPEEDS (Ve) ARE:-

FOR AREA 'D' - PLEASE CONTACT ALTRON FOR FOUNDATION SPECIFICATION

A= 41.8m/s(93m) B=45.6m/s(102m) C=50m/s(111m ASL)